




















































































Pushbutton	Description	Contact	Circuit	Color	Sign	Type	Contour
 BY2-EA42	Flush button spring return	N/O		● Black ● Green ● Blue ● Yellow		BY2-EA21 BY2-EA31 BY2-EA61 BY2-EA51	
		N/C		● Red	● Red	BY2-EA42	
 BY2-EP31	Flush button (with water-proof cover) Unmarked IP65	N/O		○ White ● Black ● Green ● Blue ● Yellow		BY2-EP11 BY2-EP21 BY2-EP31 BY2-EP61 BY2-EP51	
		N/C		● Red	● Red	BY2-EP42	
 BY2-EA4322	Flush button spring return Marked	N/O		● Green ● Green ○ White ● Black	  ↑ or ↓   ↑ or ↓	BY2-EA3311 BY2-EA3361 BY2-EA3341 BY2-EA3351	
		N/C		● Red	 stop	BY2-EA4322 BY2-EA4342	
 BY2-EL31	Convex button spring return Marked	N/O		● Black ● Green ● Blue ● Yellow		BY2-EL21 BY2-EL31 BY2-EL61 BY2-EL51	
		N/C		● Red	● Red	BY2-EL42	
 BY2-BL4322	Convex button spring return Unmarked	N/O		● Green ● Green ○ White ● Black	  ↑ or ↓   ↑ or ↓	BY2-EL3311 BY2-EL3361 BY2-EL3341 BY2-EL3351	
		N/C		● Red	 stop	BY2-EL4322 BY2-EL4342	
 BY2-EG21	LH position	N/O		2 Position stay put		BY2-EG21	
	LH and RH position	N/O+N/C		2 Position stay put		BY2-EG25	
	Center Position	N/O+N/O		2 Position spring return		BY2-EG45	
				3 Position stay put		BY2-EG33	
				3 Position spring return		BY2-EG53	

Pushbuttons

Pushbutton	Description	Contact	Circuit	Color	Sign	Type	Contour		
 BY2-ED21	Standard handle	N/O		2 Position stay put		BY2-ED21			
		N/O+N/C		2 Position stay put 2 Position spring return		BY2-ED25 BY2-ED45			
		N/O+N/O		3 Position stay put 3 Position 2 spring return to centre		BY2-ED33 BY2-ED53			
 BY2-EK2365	Standard handle with LED 2 Position stay put 3 Position stay put	N/O+N/C 220~240V		○ White/PW ● Green/PG ● Yellow ● Pure blue ● Red		BY2-EK2165 BY2-EK2365 BY2-EK2565 BY2-EK3665 BY2-EK3465			
		 BY2-EJ41	N/O		2 Position stay put 2 Position spring return			BY2-EJ21 BY2-EJ41	
			N/O+N/C		2 Position stay put 2 Position spring return			BY2-EJ25 BY2-EJ45	
 BY2-EKJ2365	Long handle with LED 2 Position stay put 3 Position stay put	N/O+N/C 220~240V		○ White/PW ● Green/PG ● Yellow ● Pure blue ● Red		BY2-EKJ2165 BY2-EKJ2365 BY2-EKJ2565 BY2-EKJ3665 BY2-EKJ3465			
		 BY2-ET42	N/C		● Red	● φ 40		BY2-ET42	
			N/O+N/C		● Red	● φ 40		BY2-ET45	
 BY2-ES142	Turn to release by key (n° 455)	N/C		● Red	φ 40	BY2-ES142			
		N/O+N/C		● Red	φ 40	BY2-ES145			

Pushbutton	Description	Contact	Circuit	Color	Sign	Type	Contour	
 BY2-ES542	Turn to release Red	N/C		● Red	∅ 30	BY2-ES442		
		N/O+N/C		● Red	∅ 40 ∅ 60	BY2-ES545 BY2-ES645		
 BY2-EC42	Mushroom head Spring return	N/C		● Red	∅ 40 ∅ 30	BY2-EC42 BY2-EC442		
		N/O		● Black ● Green ● Red	∅ 40 ∅ 40 ∅ 60	BY2-EC21 BY2-EC31 BY2-ER42		
								
								
 BY2-EV63	Direct bulb included BA9s base fitting Neon (BA9S) LED	130V 220~240V 50~60Hz		○ White/PW ● Green/PG ● Red ● Yellow ● Pure Blue		BY2-EV61 BY2-EV63 BY2-EV64 BY2-EV65 BY2-EV66		
 BY2-EW3462	Direct bulb supplied Neon (BA9S) LED	N/O		○ White/PW ● Green/PG ● Yellow ● Pure Blue		BY2-EW3161 BY2-EW3361 BY2-EW3561 BY2-EW3661		
		N/C		● Red		BY2-EW3462		
 BY2-EL8425	1 flush green button marked I 1 flush red button marked O unmarked Without pilot light IP40	N/O+N/C		■ Green ■ Red	■ Green ■ Red	BY2-EL8325		
				■ Green ■ Red	■ I ■ O	BY2-EL8425		
 BY2-EW8465	Pilot light with Yellow lens Direct supply 220~240V BA9s bulb marked IP40 Neon LED (BA9S)	1 flush green button marked I 1 flush red button marked O		■ Green □ White ■ Red	■ Green ■ Red	BY2-EL8365		
		1 flush green button marked I 1 convex red button marked O		■ Green □ White ■ Red	■ I ■ O	BY2-EL8465		